

Mull Sealing

Installation Instructions



Follow these instructions to bridge two or more installed mull windows:

Things to know before you start:

- ▶ Sealants should be compatible with the building envelope's waterproofing membrane.
- ▶ Always use drip caps at the head for vertical mull windows with a nail fin.
- ▶ Order drip caps with the window order.

Nail fin application instructions:

1. Squeeze and insert the 2" x 2" foam block into the mullion gap between the extrusions. Push the block evenly in place until it rests 1/4" - 3/8" inside the gap. This will serve as a backing for the sealant.
2. Fill the void area solid with sealant. Flatten and smooth with putty knife.
3. Apply sealant bead across nail fin gap.
4. Orient and press mull cover into place. The mull cover will act as a bridge from nail fin to nail fin.
5. Seal around edges of mull cover and tool until all voids are filled. Appearance should be smooth and flat.
6. Proceed with final water proofing membrane applied over the nail fin.

Congratulations, you have successfully bridged installed mull windows.

